

ADB adapter board¹⁾

The ADB (Adapter Board) is for connecting option boards.

This is only available separately for AFE inverters and rectifier units (sizes H and K) and rectifier/regenerative units.

Board, plugged into slot	Supplementary order code	Retrofit kit and spare part (supplied loose) Order No.
ADB Backplane adapter		
2 (Slot D and E)	K01	6SX7090-0XX84-0KA0
3 (Slot F and G)	K02	

1) Attention!
Only for compact and chassis units.