

### **DTI digital tachometer interface<sup>1)</sup>**

Digital tachometers with different voltage levels can be connected at the DTI (*D*igital *T*acho *I*nterface) board. The inputs are floating.

The board enables the following signals to be connected:

- HTL encoders with differential outputs
- floating HTL encoders

- TTL encoders
- encoder cables > 150 m
- TTL output at X405
- level converter, HTL to TTL.

Board	Supplied loose Order No.
<b>DTI</b>	<b>Digital tachometer interface</b>
	<b>6SE7090-0XX84-3DB0</b>

1) Attention!  
Only for compact and chassis units.